




Garmin Nuvi 265WT Audio Replacement

Written By: Patricia Gonzalez





TOOLS:


- [Spudger](#) (1)
-

Step 1 — Audio



- Lift up the Mother Board

Step 2



- Slowly remove the Blue/Black wires to un clip the Mother Board.

Step 3



- Use the nylon spudger to remove the battery.

⚠ The regular black nylon spudger should be used whenever possible, especially around batteries and other sensitive internal components.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 08:54:04 PM.